



GT 15
Deluxe



GT 25
Deluxe



GT 25
Deluxe

Pellet Boiler

USERGUIDE

İFYIL TERMO İKLİMLENDİRME SAN. ve TİC. LTD. ŞTİ.

CONTACT INFO

Web Site : www.ifyil.com.tr

Phone: +90 (850) 346 0 362

Fax: +90 (362) 266 94 43

E-mail: info@ifyil.com.tr

Adress: Kavak Organize Sanayi Bölgesi 3. Cad. No.11
Kavak/Samsun/TÜRKİYE

CONTENTS

INTRODUCTION	5
1- IMPOTANT NOTICE	6
1-1 General Safe Warnings	6
1-2 Operating Warnings	7
2- SAFETY DEVICE	9
3- FUEL SPECIFICATIONS	10
4- TECHNICAL SPECIFICATIONS	10
5- MAIN PARTS AND DIAMENTIONS	14
5-1 GT 15 Deluxe Diamentions	14
5-2 GT 25-34 Deluxe Diamentions	15
5-3 GT 15-25-34 Deluxe Parts	16
6- INSTALLATION	17
6-1 Operating Environment	17
6-2 Electrical Connections	18
6-3 4.3. Plumbing Schema	18
6-3-1 Plumbing installation schema	19
6-3-2 Anti Condensation Valve Connection	22
6-3-3 Heating Circulation Pump	22
6-3-4 Gate Valve	23
6-3-5 Three Way Mixing Valve	23
6-4 Ventilation And Air Flow	23
6-5 Chimney Instructions	23

6-6 Smoke Pipe Instructions	24
6-7 Suitable Shapes Of Chimney	25
7- MOTHERBOARD CONNECTION SCHEMA	31
8- CONTROL PANEL	30
8-1 User Menu Screen -1	30
8-2 User Menu Screen -2	31
8-3 Information Menu	32
8-4 Chrono Setup Menu	33
8-5 Error Codes	34
9- OPERATING	35
10- FUEL CALIBRATION	35
11- PUMP WARNING LAMP	38
12- MAINTENANCE and CLEANIG	39
13- PROBLEMS, CAUSES and SOLUTIONS	45
14- SIGNIFICIANT INTRUCTIONS for EFECTUVE USING	48
15- SUGGESTIONS and FEEDBACK	48
CERTIFICAE OF WARRANTY	49
WARRANTY CONDITIONS	50

INTRODUCTION

Dear Friend of iFYIL;

iFYIL TERMO İKLİMLENDİRME SAN. Ve TİC. LTD. ŞTİ. we manufacture the most efficient hydro pellet boiler with utmost care for our distinguished customers. So, please read this userguide carefully before starting to use our boiler and keep it as a reference in any case.

This user guide;

- **GT 15 Deluyxe**
- **GT 25 Deluxe**
- **GT 34 Deluxe**

Products includes.

Information



This symbol highlightens the significant details for correct usage of boilers. If the warnings are ignored, product will not be fully correct®ular and this can cause customer unsatisfaction. and this can cause customer unsatisfaction.

Attention



This symbol highlightens the possible serious risks during operation of boiler. So this userguide should be read carefully before using the boiler and utmost attention should be paid to the warnings.

- ** Combustion Chamber / Combustion Pot
- ** Pellet Feeder Motor / Fuel Supply Motor
- ** Mechanic Pressure Sensor / Prosestat

These side-by-side expressions have the same meanings.

1- IMPORTANT NOTICE

1-1 General Safety Warnings

- Read the operating instructions carefully before using the product.
- The product should be installed in accordance with the legislation of the country in which it will be used and the necessary safety precautions should be taken. Otherwise iFYIL will not accept any responsibility.
- This is a pellet boiler, so, please only use wood pellet as fuel.
- Please do not put water on the boiler during operation.
- Pay attention to the operating pressure of the pellet boiler. The operating pressure of the pellet boiler must not exceed the maximum permissible operating pressure given on the identification plate.
- Do not plug off while operating, please initially switch off, this operation is very vital for the cooling and efficiency of the boiler.
- It is necessary to use defined fuel in order not to damage the electronic and mechanical parts working in the device.
- Installation, electrical connection, function test and maintenance must only be carried out by authorised and qualified personnel.
- Any change on the boiler should be done by authorized person or company.
- A bad use or improper maintenance of the product can bring to problem in the combustion chamber.
- Only spares parts advised by producer should be used.
- Please do not operate the boiler before cleaning the combustion pot.
- This product should be used by adult people.
- If there is a fire in the flue pipe, extinguish the boiler, disconnect it from the power supply and never open the door. Then contact the competent authorities.
- Install the product in a location that does not present a fire hazard and is equipped with power and air supplies and smoke extractors.
- In the event of a malfunction with the ignition system, do not force it to light by using flammable materials.
- Disconnect the product from the 230V power supply before performing any maintenance operation.
- If the product is not working properly, please turn it off. Contact an authorized service

- Check the smoke outlet channels periodically.
- Frost protection measures must be taken. (Antifreeze)
- To prevent freezing, the boiler room temperature should be kept above +10 oC.
- The product should only be used as intended. Different uses cause hazards.
- Do not open the covers and sections where the electrical equipment is located, without disrupting the main energy of the system.
- Do not touch the wet hand as the product is an electrical appliance. Switch off the power when any action is required.
- The boiler must not be operated if the combustion chamber and the ash chamber door are open or the sight glass is broken.
- Avoid direct contact with hot surfaces.
- Do not insert your hand into the pellet tank and the combustion chamber while the boiler is operating
- Never install the boiler in environments with flammable, explosive, combustible gases and material
- Periodically check the smoke outlet ducts for blockage.
- Pellet boilers should not be installed in the living area. Should not wait a long time in the place where the boiler works.
- Ifyil Boilers shall not be installed in open areas, damp areas, environments in direct contact with external environment.
- Should not do any operation to flue pipe and / or water pipe when boiler operating.
- Prevent to flow by creating pressure systems should not be used to In chimney channels and water installation.
- Please comply with these rules if there are local rules or norms for the solid fuel chimney according to country regulations. If there are

1-2 Operating Warnings

- Installation of pellet stoves, fireplaces and boiler systems; should be done in accordance with electrical connections and installation diagram
- The heat requirement of the place to be heated should be checked and the appropriate boiler should be selected.
- Power supply should be used during long-term power outages.
- Automatic air purifier must be in the system.
- When the boiler is process of fire on, do not open the ash purge cover.
- You don't put the any materials (foreign materials) in the fuel tank.

- Our company does not accept any responsibility for problems due to installation of the boiler in unsuitable places.
- If using room thermostat, it should be placed at least 1,5 m from the floor. It should not be placed where the temperature changes continuously and heat loss is observed.
- The place where boiler must be equipped with:
 - oElectrical power 230V 50Hz.
 - oGrounding plug.
- If there is no ground connection it should be provided immediately.
- Fresh air must be provided from outside.
- Please, use the Voltage regulator for voltage fluctuation.
- Burning pot, ash box and air inlets should be cleaned.
- Boiler and chimney connector must be connected to an existing chimney or an external double-walled chimney. Pipe inner diameter must be 100 mm.
- Pellet boiler must be installed as close as possible to the chimney. (Chimney connection must be shorter.)
- Boiler is not suitable for a shared chimney system.
- Our company is not responsible for any problems that may arise from the use of chimneys that are not in compliance with chimney pipe standards.
- The product is out of warranty if an anticondenser valve is not used.
- Fuel loading must be performed from the test menu to the fuel tank from the helix to the pot at the first start.
- The pellets should not be handed into the combustion pot by hand.
- The boiler should not be washed with water.
- Due to the obstruction of the pot holes, abnormal gases may be formed and combustion may be delayed. • Do not use air ducts that do not comply with the installation requirements.
- Choke clogged due to lack of maintenance makes it difficult to ignite.
- The maximum fuel filling height recommended for the fuel tank of the boiler is 5 cm below the top level of the tank.
- Improper installation, use and insufficient maintenance will cause an increase in malfunctions.
- If the ignition does not occur properly, the boiler must be closed and the combustion chamber cleaned.
- The product should be stored in a dry place and not exposed to unfavorable weather conditions.

- If the boiler is not to be operated for a very long time, it must be kept in water without any water.
- The lime layer that can be formed in the water parts of the boiler decreases the boiler efficiency and causes the boiler to overheat. Therefore, necessary precautions should be taken against lime. (Lime remover chemical)



Customers not obeying the above requirements and schemas cannot claim any right for any problem. In any case, contact your dealer or IFYIL.

2- SAFETY DEVICE

- On - Off Switch
- Closed expansion tank
- Chimney temperature sensor
- Fuel tank temperature sensor
- Boiler water temperature sensor
- Boiler safety thermostat
- Mechanical pressure sensor
- Safety valve
- Air purifier

3- FUEL SPECIFICATIONS

Wood pellets are manufactured by hot-extruding compressed sawdust which is produced during the working of natural dried wood. The compactness of the material comes from the lignin which is contained in the wood itself, and allows the production of pellets without the use of glues or binders. Depending on the wood varieties and mixtures, the pellet varies.

Wood pellet fuel with quality ENplus-A1 + A2 should be used.

Definitions	ENplus A-1	ENplus A-2
Diameter	6 mm	6 mm
Lenght	≤ 30 mm	≤ 30 mm
Net Calorific value	≥ 16,5 MJ/kg ≥ 3941 kcal/kg	≥ 16,5 MJ/kg ≥ 3941 kcal/kg
Moisture Content	≤ %10	≤ %10
Ash Content	≤ %0,7	≤ %1,2
Density	750 ≥ BD ≥ 600 kg/m3	750 ≥ BD ≥ 600 kg/m3



Storage of pellet fuel;

Pellets should be kept in the dry, not too cold area. Care should be taken to store and transport pellet bags. Pellet fuel breakage should be avoided.



Dear Consumer;

In case of using pellets with chemical substances such as MDF and chipboard, your product will be out of warranty as the device may be damaged.

Defined fuel must be used in order to prevent damage to the electronic and mechanical parts running inside the device.

4- TECHNICAL SPECIFICATIONS

This device should be installed in accordance with the related regulation and EU standards.

EN 303-5 Heating boilers for solid fuels, manually and automatically stoked, nominal heat output of up to 500 kW- Terminology, requirements, testing and marking

2006 / 42 / AT- Machinery Directive

TECHNICAL DOCUMENTATION FOR SOLID FUEL BOILERS ACCORDING TO REGULATION EU 2015/1189 AND 2015/1187

Description: Solid fuel boiler fired by wood pellets

Fuel Description: Ø 6 / L:30 EN Plus A1-A2 wood pellets

Harmonized Standard: EN 303-5 Class 5

iFYIL - GT 15

Stoking mode: Automatic: It is recommended that the boiler be operated with a hot water storage tank of a volume of at least 300 L

Condensing boiler: NO

Solid fuel cogeneration boiler: NO

Combination boiler: NO

Fuel	Preferred fuel (only one):	Other suitable fuel (s):	η_s (%x):	Seasonal space heating emissions(****)			
				PM	OGC	CO	NOx
				(x) mg/m3 at %10 O2			
Compressed wood in the form of pellets or briquettes	YES	NO	82	22	9	375	163

Cracteristics when operating with the preferred fuel only:

Seasonal space heating energy efficiency η_s [%]: **82**

Energy efficiency index EEI: **120**

Item	Symbol	Value	Unit		Item	Symbol	Value	Unit
Useful heat output					Useful efficiency			
At rated heat output	P_n (***)	15,3	kW		At rated heat output	η_n	85,1	%
At [30 %/50 %] of rated heat output, if applicable	P_p	4,5	kW		At [30 %/50 0/0] of rated heat output, if applicable	η_p	85,2	%
For solid fuel cogeneration boilers: Electrical efficiency				Auxiliary electricity consumption				
				At rated heat output	e_{lmax}	0,035	kW	
At rated heat output	$\eta_{el,n}$	N.A.	%	At [30 %/50 0/0] of rated heat output, if applicable	e_{lmin}	0,012	kW	
				Of incorporated secondary emission abatement equipment, if applicable		N.A.	kW	
				In standby mode	P_{SB}	0,002	kW	
Tel. +90 850 346 0 362 www.ifyil.com.tr info@ifyil.com.tr		Manufacturer: İFYİL TERMO İKLİMLENDİRME SAN. TİC. LTD. ŞTİ. Kavak OSB 3. Cad. No: 11 Kavak/Samsun/TURKEY						

(**) Tank volume = 20 x Pr with Prindicated in kW

(***) For the preferred fuel Pn equals Pr

(****) PM = particulate matter, OGC = organic gaseous compounds, CO = carbon monoxide, NOX = nitrogen oxides

Issue date: 15.10.2021

General Manager

Harun Reşit ÖZER

TECHNICAL DOCUMENTATION FOR SOLID FUEL BOILERS ACCORDING TO REGULATION EU 2015/1189 AND 2015/1187

Description: Solid fuel boiler fired by wood pellets

Fuel Description: Ø 6 / L:30 EN Plus A1-A2 wood pellets

Harmonized Standart: EN 303-5 Class 5

IFYIL - GT 25

Stoking mode: Automatic: It is recommended that the boiler be operated with a hot water storage tank of a volume of at least 300 L

Condensing boiler: NO

Solid fuel cogeneration boiler: NO

Combination boiler: NO

Fuel	Preferred fuel (only one):	Other suitable fuel (s):	η_s (%x):	Seasonal space heating emissions(****)			
				PM	OGC	CO	NOx
				(x) mg/m3 at %10 O2			
Compressed wood in the form of pellets or briquettes	YES	NO	82,5	20	8	170	164

Cracteristics when operating with the preferred fuel only:

Seasonal space heating energy efficiency η_s [%]: **82,5**

Energy efficiency index EEI: **121,1**

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Useful heat output				Useful efficiency			
At rated heat output	P_n (***)	25	kW	At rated heat output	η_n	85,36	%
At [30 %/50 %] of rated heat output, if applicable	P_p	7,5	kW	At [30 %/50 0/0] of rated heat output, if applicable	η_p	86,01	%

For solid fuel cogeneration boilers: Electrical efficiency

				Auxiliary electricity consumption			
				At rated heat output	e_{lmax}	0,035	kW
				At [30 %/50 0/0] of rated heat output, if applicable	e_{lmin}	0,012	kW
				Of incorporated secondary emission abatement equipment, if applicable		N.A.	kW
At rated heat output	$\eta_{el,n}$	N.A.	%	In standby mode	P_{SB}	0,002	kW

Tel. +90 850 346 0 362
www.ifyil.com.tr
info@ifyil.com.tr

Manufacturer: İFYİL TERMO İKLİMLENDİRME SAN. TİC. LTD. ŞTİ.
Kavak OSB 3. Cad. No: 11 Kavak/Samsun/TURKEY

(**) Tank volume = 20 x Pr with Prindicated in kW

(***) For the preferred fuel Pn equals Pr

(****) PM = particulate matter, OGC = organic gaseous compounds, CO = carbon monoxide, NOX = nitrogen oxides

Issue date: 15.10.2021


General Manager

Harun Reşit ÖZER


Technical Specifications			Measured Values		
			GT 15	GT 25	GT 34
			Deluxe	Deluxe	Deluxe
Fuel Consumption		kg/h	1,05-3,5	1,7-5,7	2,4-7,1
Permissible Operating	Maximum	°C	80		
	Minimum	°C	65		
Maximum Operating Pressure		bar	3		
Test Pressure		bar	4,5		
Boiler Water Volume		L	41	50	50
Recommended Flue pipe draft		Pa	12 ± 2		
Fuel Tank Capacity		kg-lt	135-230	135-230	
Weight (cihaz)		kg	231	280	
Dimensions (cihaz) (WxDxH)		mm	1460x1120x595	1531x1171x595	
Connections	Delivery/Return Pipes	inç	1		
	Safety drain connection	inç	1/2		
	Combustion Air Intake	mm	Ø60		
	Chimney connection diameter	mm	Ø100		
Electric Consumption		W	200		
Electric Connection		Vac/Hz	230/50		
Flue Gas Tempera-	Nominal Heat Output	°C	100,36	148	183
	Reduced Heat Output	°C	77,21	81	80

5- MAIN PARTS AND DIAMENTIONS


5-1 GT 15 Deluxe Diamentions



5-2 GT 25-34 Deluxe Dimensions



5-3 GT 15 - GT 25 - GT34 Deluxe Parts



NO	DEFINITIONS
1	Front Cover
2	Combustion Chamber Cover
3	Manometer
4	Top Cover
5	Turbulator Rods
6	Pelet tank Covers
7	Primary combustion air inlet (ø60 mm)
8	Pump
9	Service Intervention Cover
10	On/Off
11	Hot Water Outler
12	Mainboard Cover
13	Heat Exchanger Connection
14	Chimney Outlet (ø100 mm)

6- INSTALLATION

6-1 Operating Environment

- If the boiler is placed on a flammable floor, appropriate insulation measures must be taken.
- If the boiler is placed close to the flammable walls, the wall must be insulated.
- The place where the device is to be placed should bear the weight of your device and ensure that the static conditions are appropriate.
- Flammable products must be kept at a safe distance from the risk of fire.
- Install the product in locations equipped with fire risk.
- The product should be placed so that it can provide the air required its for combustion. (It must be installed in a safe distance for air circulation.)
- The room volume 30 m³ shall not be less than.




Figure 6.1 Güvenli Safe Minimum Distance



It is recommended to have a fire extinguisher in order to prevent a fire.


6-2 Electrical Connections

First insert the power cable into the back of the boiler, then insert the cable outlet. Opening the back of the boiler on / off switch to turn on your boiler, bringing the open position

A voltage regulator using is required in areas with voltage irregularities. Electronic and electronic card failures that may occur due to the absence of a voltage regulator are not covered by the warranty.

Recommended specifications for the voltage regulator: 2 Kva automatic voltage regulator with relay 135-265 V

Recommended specifications for the power supply: 2 Kva




Use your boiler and running in a socket with ground.

6-3 Plumbing Schema


- 120 cm and longer radiator must be connected to the installation with a reverse connection.
- Hydro boiler's connections must be made with conical iron union.
- Installation should be with fill and drain valve in definitely.
- Safety valve is installed on body.
- Safety valves must be in the water outlet. The safety valve is mounted on the body.
- Boiler lit (off) the water pressure should be in the range of 1-1,5 bar. Otherwise drain / refill valve should be checked.
- It is recommended to install a thermostatic valve in the radiators to ensure that the room temperature can be kept to the desired degree and to provide high comfort at low cost.
- Hot water circulation pump, Bridge valve, Mixing valve shall be supplied by the user. The TS 1258 "Rules for Calculation for Installation Water Supply on Building" Standard must be observed in the selection of these equipment.

Plumbing Connections


* Example schema - 1




* Example schema - 2





























* Example schema - 3



* Example schema - 4




	Solid Fuel Boiler - Stove		Heat Exchanger		Underfloor Heating
	Boiler		A set of fixed value settings		
	Ball Valve Or Butterfly Valve		3 Way Motorized Valve (Boiler priority)		Radiator Plumbing
	Strainer		3 Way Motorized Valve (Mixture)		
	Check valve		Expansion Tank		FCU Plumbing
	Anti Condensate		Manometer		
	compensator		Thermometer		Domestic Hot Water Plumbing
	Recirculation pump		Lock Valve		
	Air Separator		Safety valve		Pool Plumbing
	Balance Cup		Drain Valve		
	Sediment Trap				

6-3-2 Anti Condensation Valve Connection Schema

Anti condensate valve; By automatically adjusting the temperature of the water entering the boiler to the calibration value (55 ° C), it prevents the condensation of water vapor in the smoke.

Anti condensate valve is a system in which the boiler is circulated to the outlet water to bring it to the appropriate temperature. In order to check the temperature of the water entering the solid-fueled boiler during and after the first start-up phase, it performs a mixing operation between the inlet water and the leaving water.



Connection Locations;

A - Radiator Cold Water Return Line
B - Boiler Hot Water Outlet Line
AB - Boiler Cold Water Return Line



Assembly and dismantling; it should always be carried out when the system is cold and unpressurized.
Access; valve access must be not prevented in order to allow maintenance of valves or piping equipment



Warranty Coverage Warning;
As the anticondensation valve is used, it is necessary to use heating circulating pump and gate valve. The product is not covered by the warranty when the Anti-Condensation valve isn't use.

6-3-3 Heating Circulation Pump

The heating circulating pump with the same values as the circulating pump values should be used.

6-3-4 Gate Valve

Anticondens should be applied to prevent the heating circulating pump from being damaged when the valve is closed.

6-3-5 Three Way Mixing Valve

The mixing valve is a mixing valve that brings the hot water from the heating system to the desired temperature by mixing it with the cooling water in the heating system.

Features;

- The Kv value should be minimum 30 m³ / h.
- The pressure loss of the 3-way mixing valve must be a maximum of 0.1 mSS.
- 3-way mixing valve outlet diameters must be 1 ¼”.



The heating circulating pump, the gate valve, the mixing valve shall be supplied by the user.

6-4 Ventilation And Air Flow

- In the ambient where the boiler is installed, there should be enough air to allow regular combustion.
- The location of boiler fresh air inlet must be provided.
- It is recommended that the boiler should be connected to an environment (external environment) where the air suction pipe can be continuously flowing clean air with hermetic pipe.
- Use 300 cm² lower, 200 cm² upper orifice. These grilles should never be closed. Otherwise, it presents a great danger.
- Avoid installing the unit in the same environment with the following;
 - oB type gas heaters or exhaust fan or fanless hoods
 - oCollective ventilation pipes.
 - oAspirator device running in the same environment, can cause problems.

6-5 Chimney Instruction

The main cause of the chimney fire;

- Improper selection or pipe that dust is flammable fuel.
- In the event of appropriate conditions can cause fires ignite in the ducts.

Ways of avoiding them;

- The chimney should be cleaned at least 2 times per year, depending on the fuel quality.
- Correct and appropriate chimney selection should be made.
- Ensuring that the sealing and smoke in the chimney pipe and must be made in isolation.
- Fresh air intake area of the ducts that maintaining and cleaning the boiler is installed
- Surrounding the peak point of the roof of the chimney to the interference of the obstacle (the ridge) from height must be at least 80 cm.
- Should chimney's pipe inner diameter is 100 mm
- Chimney flue test should be performed before making connections. If the chimney connections should be carried out after removal of the traction problem had this problem in the chimney.
- The boiler pipe connected to the horizontal flue pipe must not be longer than 2m. It is recommended to use 45 ° elbows in chimney pipes instead of 90 ° bend. (Site selection for boilers should be determined by the closest point where the chimney.)
- In case of a re-ignition after prolonged period of time, the smoke paths and flue congestion must be checked.
- To avoid turbulence around the chimney flue without any obstructions (high buildings, trees, etc.) Must be at least 10 m away.
- The pellets boiler should be mounted as close to the chimney as possible (chimney connection should be short).
- Chimney cap should be used to prevent the flow into the chimney flue repercussions of windy weather and rain.
- Concrete blocks is affected by temperature changes, concrete flat roof which is in direct contact with the air must be absolutely isolated.
- An accurate and sufficient flue system for smoke extraction (a chimney with natural traction (2 Pa - 8 Pa) that does not backfire in the event of a power outage.) is necessary.
- Necessary precautions should be taken to prevent condensate formed in the chimney from reaching the boiler.
- Clogging or closing of the flue outlet poses a great danger.



Boilers must be connected to a chimney duct which can move vertically smoke outside the building or its flue pipe to the highest point of the building.

Chimney connections, if that would be considered illegal in the first combustion fumes can cause the wall to infiltrate the processing of these leaks may leave traces. Leaked smoke and / or flames can cause burns or fire because it can be very hot.

6-6 Smoke Pipe Instruction

- Horizontal chimney's duct and vertical chimney's pipe connections are very important, therefore, it must be done carefully. Warranty of the smoke pipe connection should be made accordingly.

- The minimum safety opening surface sections should be 15%. Slope in the horizontal section of the pipe should be 3-5%. (3-5 cm per meter). The horizontal chimney's duct should not be longer than 2 m.
- The boiler chimney pipe inner diameter is 100 mm.
- Horizontal chimney's duct and vertical chimney's pipe should be made of durable materials for heat, corrosion and condensation.
- Please take care of flue pipe standard sizes, the problems in case of using nonstandard sizes will not be under our responsibility

6-7 Suitable Shapes Of Chimney

The remaining section of the chimney outside the home, it must be insulated. The smoke in the event of an electrical failure of your boiler with a natural drive capable throw out the chimney must be applied.




Figure 5.2 Suitable chimney shapes




Figure 5.3 Suitable chimney shapes





Figure 5.4 Improper chimney shapes



HOUSES AND OFFICES NOT OBEYING THE ABOVE MENTIONED STANDARDS ARE POTENTIAL FOR FIRE AT ANYTIME AND CARBON MONOXIDE (CO) GAS LEAKAGE. PLEASE FOLLOW THE ABOVE MENTIONED INSTRUCTIONS! BY SO, CLIENT ACCEPTS IN ADVANCE THAT IN SUCH CASES MANUFACTURER DOESN'T HAVE ANY RESPONSIBILITIES CLIENT NOT FULFILLING ABOVE MENTIONED REQUIREMENTS IN SCHEMAS CANNOT CLAIM ANY RIGHT OR COMPENSATION.

7- CONNECTION SCHEMAS

Model: GT 15 Deluxe / GT 25 Deluxe / GT 34 Deluxe






In Plus models; The bridge located on the motherboard (on inputs 24-25 (MB100: IN 5 / NG01: IN 3)) can be removed and the room thermostat can be connected instead. (In Standard models, room thermostat cannot be connected.).

8- CONTROL PANEL

Date and time, Chrono state, temperature of the local room in use, local room thermostat in use, error signalling, combustion power, heating power



Selection keys

P1	Exit from menu/submenu Refill Function (press for 3 seconds)	P4	Enter in Combustion power menu Increase
P2	Ignition and extinguishing (press for 3 seconds) Errors Reset Enabling/disabling chrono	P5	Enabling Chrono time slot Enter in Information Menu
P3	Enter in User menu 1/submenu Enter in User menu 2 (press for 3 seconds) Save data	P6	Enter in Room Thermostat Menu/Boiler Thermostat Decrease
P3+P5 For 3 seconds		Direct Enter in Secondary Information Menu present in Service Menu	

Led

D ☼	Daily Mode Chrono ON	24H	24 heating function enabled
W ☼	Weekly Mode Chrono ON		
WE ☼	Weekend Mode Chrono ON		
C	Combi Functioning		DHW demand or buffer thermostat not satisfied
	Wood Functioning		Room heating target achieved
	Lack of fuel in the tank/Level of material in the tank within 0% and 10%		Level of material in the tank within 10% and 35%
	Level of material in the tank within 35% and 60%		Level of material in the tank within 60% and 80%
	Level of material in the tank within 80% and 100%		Climatic Function activated
	Summer		Winter

8-1 User Display Menu -1

USER MENU

Functioning	<p>Menu that allows you to change the system functioning, passing from Wood to Pellet mode and vice versa or to select the Combi mode. This Menu is displayed only if P11=2, 3, 4.</p> <p>The transition from one operating mode to another can only occur in the following cases:</p> <ul style="list-style-type: none"> From Off mode you can select any of the three options with system On and P11=2, the functioning can't be modified with system On and P11=3, from the functioning Wood only you can switch to Combi mode with system On and P11=4, from the functioning Wood/Pellet only you can switch to Combi mode
Power	<p>Pellet</p> <p>Menu to modify the combustion power of the system in Pellet mode. It can be set in automatic or manual modality: in the first case the system will choose the combustion power; in the second case the user selects the power. On the left side of the display is shown the combustion modality (A=automatic combustion, M=manual combustion) and the working power of the system. It is displayed if P11 is different from 1.</p>
	<p>Wood</p> <p>Menu to modify the combustion power of the system in Wood mode. It can be set in automatic or manual modality: in the first case the system will choose the combustion power; in the second case the user selects the power. On the left side of the display is shown the combustion modality (A=automatic combustion, M=manual combustion) and the working power of the system. It is displayed if PA36=1 and P11 is different from 0.</p>
	<p>Heating</p> <p>In this menu is possible to modify the heating power of the system. It can be set in modality automatic or manual: in the first case the system will choose the combustion power; in the second case the user selects the power. On the display right side is shown the heating mode (A=automatic, M=manual) and its power.</p>
Thermostats	<p>Boiler</p> <p>Menu to change the value of the Boiler Thermostat. Minimum and Maximum value can be programmed by setting Thermostats Th26 and Th27; with activated climatic function and hydraulic plant different from 2, 3 or 9 The menu is not displayed, because the thermostat value is calculated automatically by the system.</p>
	<p>Buffer</p> <p>This Menu allows you to modify the value of the Buffer tank Thermostat; it is displayed only if a hydraulic plant which provides for it is selected. Minimum and maximum value can be programmed by setting the Thermostats Th51 and Th52. With climatic function switched on and P26=4, 8 its value cannot be changed, because it is calculated automatically by the system.</p>

8-2 User Display Menu - 2

DHW

This Menu allows you to modify the value of DHW Thermostat. It is displayed setting the parameter **P26=2, 3, 10, 11**. Maximum value can be programmed by setting the Thermostat **Th83**.

Supply

This Menu allows you to modify the value of the Supply Thermostat. It is displayed only if a hydraulic plant which provides for the use of the Supply probe is selected (**P26=9**). Minimum and maximum value can be programmed by setting the Thermostats **Th71** and **Th72**.

With climatic function switched on its value cannot be changed, because it is calculated automatically by the system.

Room

This Menu allows you to modify the value of the local room thermostat. It is displayed if an input is configured as room probe or if the remote control 2Ways2 is on.

Remote Room

This Menu allows you to modify the value of the remote keyboard room thermostat. It is visible only in the remote keyboard if **A52>0**.

It allows programming and enabling ignition/extinguishing of the system. It consists of 2 submenus.

8-3 Information Menu

INFORMATION

Display		Unit	Description
K	CP		
Exhaust flue gas T.	tF	[°C]	Exhaust flue gas temperature
Flame Light	Lt	[%]	Flame Light; it is displayed only if an input has been set as Photoresistance
Water T	-	[°C]	Boiler temperature
Room T.	tA	[°C]	Local room temperature; it is displayed if an input has been set as Room probe or if the remote control 2Ways2 is on
Buffer tank T.	tP	[°C]	Buffer tank temperature; it is displayed if an input has been set as Buffer tank probe
Low Buffer tank T.	tPL	[°C]	Low buffer tank temperature; it is displayed if an input has been set as Low Buffer tank probe
DHW T.	tb	[°C]	DHW Temperature; it is displayed if an input has been set as DHW probe\
Supply T.	tM	[°C]	Supply temperature; it is displayed if an input has been set as Supply/Return probe
Collector T.	tC	[°C]	Solar collector temperature. Visible only if one input is configured as solar collector probe
Water Pressure	PA	[mbar]	Water Pressure; it is displayed if an input has been set as Water Pressure Sensor
External T.	tE	[°C]	External temperature; it is displayed if an input has been set as external probe
-	FL	-	Air Flow; it is displayed if an input has been set as Primary Air Regulator
-	Pr	[Pa]	Vacuum pressure; it is displayed if an input has been set as Vacuum sensor
-	UF	[rpm]	Speed of the Exhaust flue gas fan; it is displayed only if rZ3 is different from 0
-	Co	[s]	ON time of the Auger; it is displayed if P81 is the same as 0
Recipe	rC	[nr]	Combustion Recipe Selected; it is displayed if P04 is greater than 1
Service	St	[h]	Functioning time left before the system displays the message 'Service'; it is displayed if T66 is greater than 0.
Clean	St2	[h]	Functioning time left before the cleaning of the stove; it is displayed if T67 is greater than 0.
Pellet	PL	[%]	Estimated pellet remaining in the tank
-	FunC	-	Summer (<i>Est</i>) /Winter (<i>InU</i>) Modality functioning
-	nGHt	-	State of the Night Mode function
-	FC	-	Firmware Code and Revision: FYSr03000002.x.y
-	xyzt 568	-	Product code

8-4 Chrono Setup Menu

This menu allows to set the Ignition-Extinguishing method and time intervals.

	<p>Mode</p> <p>It allows you to select the mode of your choice or to disable all the set programs.</p> <ul style="list-style-type: none">• enter modify mode with the key P3• select the mode of your choice (Daily, Weekly or Weekend)• enable/disable chrono mode with the button P2• save the new settings with the key P3 <p>Program</p> <p>The system has 3 programs: Daily, Weekly, Weekend. After selecting the program of your choice:</p> <ul style="list-style-type: none">• select the time with the buttons P6 or P4 (P5 or P4 for the K100)• enter the modify mode (the selected time flashes) with the button P3• modify the time with the buttons P6 or P4 (P5 or P4 for the K100)• save the new settings with the button P3• enable (a "V" is displayed) or disable the time slot (a "V" is not displayed) pushing the button P5 (P2 for the K100) <p><i>Daily</i></p> <p>Select the day of the week of your choice and set the ignition and extinguishing times.</p> <p><i>Program across midnight</i></p> <p>Set an ON time of the day before of your choice: Ex. 20:30 Set the OFF time of the day before at 23:59 Set the ON time for the next day at 00:00 Set the OFF time of the next day of your choice: Ex. 6:30 The system will turn on at 20:30 on Tuesday and will turn off at 6:30 on Wednesday</p> <p><i>Weekly</i></p> <p>The programs are the same for all the days of the week.</p> <p><i>Weekend</i></p> <p>Choose between the time slots Monday-Friday and Saturday-Sunday and set the time for ignition and extinguishing.</p>	<div>Disabled</div> <div>Daily Weekly Weekend</div> <div>Monday</div> <table><tr><td>ON</td><td>OFF</td></tr><tr><td>09:30</td><td>11:15 V</td></tr><tr><td>00:00</td><td>00:00</td></tr><tr><td>00:00</td><td>00:00</td></tr></table> <div>Monday</div> <div>Tuesday Wednesday Thursday</div> <div>Mon-Fri Sat-Sun</div>	ON	OFF	09:30	11:15 V	00:00	00:00	00:00	00:00
ON	OFF									
09:30	11:15 V									
00:00	00:00									
00:00	00:00									
Night Mode *	<p>Menu to set and enable the beginning and ending time slots of the engine.</p> <p>The time slots programming is the same as in Chrono Menu. To program it across midnight, set a time slot until 23:59 and the following from 00:00 to the time of your choice.</p> <p>Night Mode allows you to disable in the set time slots the functioning of the following Engines: Load Engine (if P100=1), Cleaning Engine (if P103=1), Cleaning Engine 2 (if P102=1), Cleaning Engine 3 (if P101=1).</p> <p>During the set times, the display shows the message <i>Night Mode</i>.</p> <p>The menu is displayed only if at least one engine is disabled in Night Mode.</p>									

8.5 Error Codes

Description	System Phase	Code
Boiler water temperature too high error (This alarm is activated when the system is	Blok	Er01
Prosestat error	Blok	Er02
Extinguishing at low flue temperature	Blok	Er03
High water temperature extinguishing	Blok	Er04
High chimney temperature extinguishing	Blok	Er05
The fuel tank is extremely hot	Blok	Er06
Fan encoder error: No encoder signal	Blok	Er07
Fan encoder error: Chimney fan adjustment failed	Blok	Er08
Fault in long-term power outage not correct day and date	Blok	Er11
Ignition error	Blok	Er12
Lock of Power	Blok	Er15
Control panel (RS485) connection error	Blok	Er16
Pellet out error	Blok	Er18
Combustion chamber engine failure	Blok	Er25
Service error	Blok	Er40 Servis

9- OPERATING

First Fire

- The pellets feeder, not provide the required amount of pellets in the tank is not full every first firing. So the pellets tank, make sure that the pellets fall into the pellets feeder.
- If not successful after several test burn, make sure the correct positioning of the combustion pot.
- Instead of the igniter is placed in the holes in the burning pot. Burning pot, make sure it is fully seated.
- Please check. Pellets left over from previous combustion and / or residues, can be an obstacle to burn pellets stuck to the firing rod. If an abnormality is found again after these checks, there may be a problem with the boiler components or installation means correctly.



For warning labels affixed on the boiler, remove before burning boiler. During the first burning boiler clean room air intake must be provided.



The smoke and odor of the protective paint on the boiler during the first combustion is short term, in this case open the doors and windows.

10- FUEL CALIBRATION

Calibration should be carried out during commissioning of the products and in case of replacement of the pellet used. The first calibration process (installation) must be performed by the service. Calibration procedure should be done when the boiler is cold and not working.

Before starting the calibration process, place a bowl where you can weigh the pellet at the drop point of the pellet. (If there is no pellet in the feeding auger, press the "Set" key. In Loading menu, move the state to On position. After to place the pellet in the bowl that you have placed, loading menu can do "off")

Press the "Set" button. Go to Loading menu and Set the status from "off" to "on" . The pellet feed will then be activated and the pellet will feed continuously for 3 minutes. At the end of this period, perform the loading again. Weigh the pellet at the end of this 6-minute loading. Compare the result of this weighing in grams. Change the P05 and T03 parameter values by selecting the closest value.



Do this only if you change the pellet that you use after the initial service and you experience a decrease in performance.

You can make the changes by following the steps below.

To change parameter P05; Press and hold the "Set" button for 3 seconds. Select " System" from the menu that appears. You will be asked to enter the password. Contact your service provider for a password. Then select "Auger" menu. You can reach the parameter value P05 with the up / down arrow keys.

To change parameter P03; Press and hold the "Set" button for 3 seconds. Select " System" from the menu that appears. You will be asked to enter the password. Contact your service provider for a password. Then select "timers" menu. You can reach the parameter value P03 with the up / down arrow keys.









The user must not change any parameters except these two parameters within the calibration process. Otherwise, the user is responsible for the loss of efficiency.

It is recommended that all these operations be performed by the service.

GT 15 Plus				GT 25 Deluxe				GT 34 Deluxe			
No	Gr/10dk	P05	T03	No	Gr/10dk	P05	T03	No	Gr/10dk	P05	T03
1	800	5,4	204	1	1000	6,3	280	1	1000	6,3	272
2	900	6	181	2	1050	6,6	271	2	1050	6,6	262
3	1000	6,5	158	3	1100	6,9	258	3	1100	6,9	252
4	1050	7	148	4	1150	7,2	247	4	1150	7,2	243
5	1150	7,5	136	5	1200	7,5	236	5	1200	7,5	235
6	1250	8	123	6	1250	7,8	226	6	1250	7,8	227
7	1300	8,5	129	7	1300	8,1	217	7	1300	8,1	220
8	1400	9,1	114	8	1350	8,4	209	8	1350	8,4	213
9	1500	9,6	107	9	1400	8,7	201	9	1400	8,7	207
10	1550	10	100	10	1450	9	194	10	1450	9	200
11	1650	10,8	93	11	1500	9,4	187	11	1500	9,4	192
12	1750	11,4	89	12	1550	9,6	181	12	1550	9,6	185
13	1800	11,9	85	13	1600	10	175	13	1600	10	180
14	1900	12,3	82	14	1650	10,3	170	14	1650	10,3	175
15	2000	12,7	78	15	1700	10,6	165	15	1700	10,6	172
16	2050	13,1	76	16	1750	11	160	16	1750	11	167
				17	1800	11,3	156	17	1800	11,3	163
				18	1850	11,6	151	18	1850	11,6	158
				19	1900	12	147	19	1900	12	153
				20	1950	12,3	144	20	1950	12,3	148
				21	2000	12,6	140	21	2000	12,6	143
				22	2050	12,9	137	22	2050	12,9	138
				23	2100	13,2	133	23	2100	13,2	133

11- PUMP WARNING LAMP

If the product is equipped with a Wilo pump with frequency converter:




LED COLOUR	MEAN	DETAILED DESCRIPTION
 Solid Green Light	Normal Operation	The pump is operating normally.
 Flashing Green Operation	 Air discharged The pump is standby mode (PWM version)	Pump will try to take the air in the system for 10 minutes. The pump then this process will not work if the maximum speed; by the user via the switch should be set to the desired value. The pump is in standby mode. (PWM version)
 Flashing red/green light	Unusul work (Pomp is stop)	The pump has stopped because of the problem. After eliminating the problem, pump self again It starts operating.
 Flashing Red Light	Pump is stop.	By turning the pump Start again. if After rebooting the still flashing red If you see light; replace pump with a new one
 No Light	There is no power supply	Energy is not going to pump.

12- MAINTENANCE and CLEANING



All cleaning of your stove, while your stove is not lit (when cold case) and make the electrical connection closed position.

When cleaning your stove; Do not use Flammable, explosive, flammable etc chemicals that may pose a hazard.



1. Top Cover
2. Turbluator arms
3. Outer cover
4. Combustion chamber cover

5. Grill table
6. Ashtray
7. Cleaning cover

Combustion Pot Cleaning;

- When cleaning the combustion Pot, open the front cover (3) and the combustion chamber cover (4).
- Move the grill table (5) back and forth.
- Visually inspect the combustion crucible for slag build-up. Remove any slag. When cleaning the crucible, make sure it is completely cold.

Ashtray Cleaning;

- Remove the ashtray (6). Clean and replace.

Turbulator – Smoke Pipe Cleaning**a. Manual Turbulator Cleaning**

- Cover 7 must be closed in Fig. 11.1 when the turbulator is cleaning.
- Open the top cover number 1 in Fig. 11.1.
- Move the Turbulator arms number 2 up and down until the turbulators are cleaned.
- Then close compartment 1 in Fig. 11.1

b. Automatic Turbulator Cleaning (Optional)

In the smoke pipes, cleaning of the particles caused by the combustion process is provided automatically.


Every time the boiler is switched off, the system will be activated at the specified time intervals to perform automatic turbulator cleaning.

Automatic turbulator cleaning will be activated automatically between 08:00- 18:00 every time the boiler is switched off / off.

b.1. Time Switch;

The time switch controls the switching on and off of the circuit at predetermined intervals in increments of 2 hours for 7 days or 15 minutes for 24 hours.

The time switch is shown in figure 11.2.



b.2. Manual Switching;

Explain of number 4 of Figure – 11.2.

Up: "O" - Contact Continuous On Mode

Middle: "⌚" - Auto Program Mod

Down: "I" - Contact Continuous Off Mode

The time switch will be sent in the "O" - Contact Continuous On mode to the user. When the boiler reaches the user, the authorized service personnel will activate the system by taking the "⌚"- Auto Program Mod.

The user should not change the time of the time c

Figure - 11.2 Time Switch

b.3. Electrical Circuit Diagram




Figure 11.3: Electrical Circuit Diagram

The Electrical Circuit Diagram Elements are numbered in Figure 11.3.

- (1)..... Time Roles
- (2).....Motherboard
- (3).....Motor
- (4).....Condenser

Smoke Box Cleaning;

- Unscrew the cleaning cover connection screws (7). Remove ashes from the smoke pipes. After cleaning, close the cleaning cover and install the fastening screws.

Cleaning \ Period	1 Day	2 Day	1 Month
Turbulator – Smoke Pipe		X	
Combustion Pot	X		
Ashtray		X	
Smoke Box			X

Table: Cleaning Periods



Cleaning periods may vary depending on pellet quality.



- After 200 hours of operation, please call the technical service for stove maintenance.
- Do not spray cleaner on painted parts or on fire gate seals.




The display shows the message "**Clean**" per 200 hours and the system gives out an acoustic signal periodically. To stop signalling access to the Menu "**Cleaning Reset**". To access this menu; Press the **Set (P3)** key once. Use the arrow keys (**P4 / P6**) from the menu to enter "**Cleaning reset**" menu with the **set (P3)** key. Set the status to "**on**". This is possible only in OFF state.

1. SAFETY DEVICES

- | | |
|------------------------------------|-------------------------------|
| 1. On-off switch | 6. Boiler safety thermostat |
| 2. Closed expansion tank | 7. Mechanical pressure sensor |
| 3. Chimney temperature sensor | 8. Safety valve |
| 4. Fuel tank temperature sensor | 9. Air purifier |
| 5. Boiler water temperature sensor | |

AUTO CLEANING SYSTEM WARNINGS

- **The switch** did not fully pass the position while the cleaning system was running and there was a power outage at that moment, the cleaning system may not be stable. In order to bring balance, the power failure alarm that appears on the screen is verified and the system menu is entered, the AUX 2 output (MB100 motherboard) and V2 output (NG01 motherboard) in the Test Outputs tab are activated with the "ON" command and the cleaning system is brought back to the **balance** .
- In the event that the cleaning system does not work or is installed due to errors that may occur during the installation, **do not intervene with your hand while** the power cable is connected . Otherwise, your hand may remain between the nails and unwanted situations may occur.
- In cases where the cleaning system does not work for different reasons, you can control the automatic cleaning system by unplugging the power cable connected to the On/ Off button on the back of the device from the socket of the On/ Off button.
- The cleaning system collects ash and slag inside the box. The end user should empty the ash and slag into the ashtray by pulling the slide of the box as shown in the figure every **2-3 days**. Do not forget to return the slider to its original position.



13- PROBLEMS, CAUSES and SOLUTIONS

PROBLEMS	POSSIBLE CAUSES	SOLUTIONS
Boiler does not start	No power supply	Make sure that the product is plugged in and the on/off button is in the on position.
	Blown fuse	Check the fuse
When the boiler in operation the temperature is not increasing.	Combustion settings	Check the parameters.
	Boiler can be dirty.	Clean the boiler.
	Pellet quality	Use the quality pellet.
Boiler is going condensation	Temperature setting	Increase the boiler temperature
	Insufficient fuel consumption	Check the technic parameters.
The radiators are not heating up.	Room thermostat may be set to low rating.	Increase the room thermostat temperature.
	Circulation pump does not work.	Check the circulation pump
	Radiators have air.	Remove the air in radiator.
The pellets are not fed into combustion chamber, or not enough into	Empty pellet tank	Pelet tankına pelet ekleyiniz.
	Sawdust has blocked the feed screw	Helezonu kontrol ediniz.
	Faulty electronic board	Call technical service
	Faulty gear motor	
Boiler is shutting down automaticly.	The pellet tank may be empty	Fill the pellet tank at the appropriate level
	Bad pellet quality	You must use quality pellet
	Pellet flow may be low	Check the pellet flow
	Combustion room may be dirty	Clean the combustion room
	Circulation pump failure	Call technical service

The boiler runs a few minutes and then the switches off	Start-up isn't completed	Rerun the Start-up
	Power cut	Wait the otomatic start
	Smoke of the duct	Clean the smoke duct.
	Temperature sensor problem	Call technical service
The smoke evacuation motor does not workv	Faulty of fan motor	Call technical service
	Mainboard faulty	
	Boiler is not powered	Sigortayı kontrol ediniz.
In automatic mod the boiler runs full-power.	Temperature sensor error.	Check the temperature sensor.
	Temperature probe problem	Check the temperature sensor.
	Degree of temperature on thermostat	Set the degree of temperature
Boiler fire in self off and / or the boiler stops automatically.	The fuel hopper is empty	Fill the fuel hopper.
	Fuel feeder does not work.	Check and call technical service for replace motor as necessary.
	The fuel temperature sensor is malfunctioning	Check and call technical service for replace sensors as necessary.
	The door is not fully closed	Close the door or replace with original spare parts.
	Unsuitable pellets.	Change to a type of pellet recommended by the manufacturer.
	Low fuel ratio	Have you checked the fuel supply rate by the technical service?
	Combustion chamber dirty.	Guide to clear the combustion chamber as indicated.
	Smoke outlet obstructed	Check if smoke duct is blocked.

Boiler is working a few minutes and then off	The ignition cycle is not completed.	Re-run the ignition cycle (turn off).
	Temperature sensors are defective or damaged.	Check and call technical service for replace sensors as necessary.
	Smoke duct is clogged	Clean smoke duct.
The pellets are stacked into the combustion bowl, cover glass gets dirty very quickly and the flames are burning low.	Insufficient combustion air comes	Check that it is edible by the boiler room constantly fresh air.
	The pellets could not damp or appropriate.	Change the type of pellets.
	Exhaust fan failure	Check. If necessary, call technical service for Replacing the flue fan motor
	Fan and Screw Calibration can be performed.	Menu> Combustion management> Fan Calibration and Screw calibration adjustable

14- SIGNIFICANT INSTRUCTIONS for EFFECTIVE USING

- Please, clean the ash before ignition the boiler.
- Please clean the inside of the glazed models with the help of cleaner and outside with the clean clothe.
- The insulated environment is recommended to use the boiler.
- Do not put any other fuel different pellet into the fuel tank and combustion pot.
- mm wood pellets to be used as fuel.
- Settings other than user settings (technical menu) must be replaced by the service.
- Please press the shut-down button to close the boiler when the boiler is open (do not take off the energy cable to turn off the boiler).
- Pellets must be reloaded if pellets remains at a height of 20 cm below the fuel tank.
- Fuel tank should not be loaded fully, 5 cm clearance should be left from the top.
- The chimney installation must be done in accordance with the instructions.
- Annual maintenance will make longer the life of the boiler.

15- SUGGESTIONS and FEEDBACK

- Please read the installation schema and user guide carefully.
- Please use wood pellets as fuel.
- Once a year, the boiler should be checked by the authorized service.
- Please do not start the boiler when the boiler door is open.
- In case of fire, please switch off the boiler and plug off, ventilate the room, call the emergency fire.
- Please use suggested pellets fuels.
- Please follow the user instructions.



Service Calls

For technical service calls, please visit www.ifyil.com.tr



Any right cannot be claimed due to the changes or modifications or wrong use of spare parts.
IFYIL original spare parts must be used for any permitted change of spare part.



REPUBLIC OF TURKEY

MINISTRY OF CUSTOMS AND TRADE

DIRECTORY OF CUSTOMERS PROTECTION AND MARKET SURVEILLANCE

CERTIFICATE OF WARRANTY

Date of issue and number of document:

Validity of document:

The Ministry of Customs and Trade with General Directorate of Consumer Protection and Market Surveillance authorized use of this document; Law No. 6502 on Consumer Protection and In accordance with the Regulation on the application principles of the WARRANTY Certificate.

MANUFACTURER COMPANY

Name: İFYIL TERMO
İKLİMLENDİRME SAN.
TİC. LTD. ŞTİ.

Address: Yeni Cami Mah. 3. Cad.
Kavak OSB Kavak/
SAMSUN/TÜRKİYE

Phone: +90 (362) 266 94 43

Fax: +90 (362) 266 94 43

E-Mail: info@ifyil.com.tr

Authorized İFYIL TERMO İKLİMLENDİRME
SANAYİ VE TİCARET LTD. ŞTİ.
Yeni Cami Mah. 3. Cad. No: 11 Kavak OSB
Kavak / Mal Müdürlüğü : 470 043 0490
Merkezi No.: 0470 - 0630 - 4900 - 0014

Signature & Stamp

PRODUCT

Type: Pellet Boiler

Trademark: İFYIL

Model:

Banderole & Serial Number:

Production Date:

Warranty Time: Two Years

Max Reperation Time: Twenty Working Days

IMPORTER / DEALER

Name:

Address:

Phone:

Fax:

E-Mail:

Invoice date and number:

Delivery date and place:

Authorized Signature:

Authorized Stamp:

CUSTOMER

Name Surname:

Address:

Phone:

Signature:

WARRANTY CONDITIONS

- 1) The warranty period starts from the delivery date of the product and is **two (2)** years.
- 2) The product is fully in warranty, except for the glass and cast parts.
- 3) In case the product is found to be defective, Article 11 of the Law No. 6502 on Consumer Protection;

a- Cancelling sales contract,

b- Asking for reduction from selling price of products,

c- Asking for free reparation,

d- Asking products to be changed with non defective one use one of this rights.

4) **In case of choosing product to be repered by consumer;** seller is obliged to repare total product without asking any reperation fee, changed parts or any costs concerning this reperation. Consumer can use this right either against manufacturer or against importer of products. Seller, manufacturer and importer are common responsible for quality of products.

5) **In case of choosing products to be repered for free by consumer;**

- If products are broken again in the warranty time is still,

- If given repair time was passed,

- If reparation is impossible and this situation is proved by service, seller, manufacturer or importer with a written report;

Consumer has total right to ask be paid the price of products, reduction price of product for damage or if possible change of completely product against not damaged ones. Seller has no right to refuse demand written here below and in negative case seller, manufacturer and importer are common responsible.

6) Reparation period can not exceed **20 working days**. In case of in warranty time this period starts from to giving information time to tecnical service or seller by customer. In case of in not valid warranty time this period starts from reception of the products to service. Importer or seller obliged to replace products with another one until reparation completed, if reparation period exceeds **10 working days**. Time for reparation will be added to total warranty time in case reparation has been done on validity of warranty term.

7) Warranty does not covers any damages due to energy cut in case of not use external power supply.

8) Warranty does not cover any damages due to high or low voltage.

9) Warranty does not covers any damages due to burning chemical used pellets or contaminated pellets.

- 10)** Product will out of Warranty when installation/any change made by non authorised personnel or services.
- 11)** Warranty does not covers any damages due to set up ifyil pellet stoves in open air areas, wet places, humid places or any place which directly related to all these places.
- 12)** Warranty does not cover any damages due to not maintenance of product which written in user's guide.
- 13)** Warranty does not cover any damages due to using product against its purpose or against rules written in user's guide.
- 14)** Warranty does not cover any damages due to **fire and natural disaster**.
- 15)** Consumer has total right to inform courts, consumer arbitration committee of their country or place of live.
- 16)** In case not issue of this warranty certificate consumer has right to apply to ministry of trade and customs of Turkish Republic.
- 17)** This warranty rules and conditions are valid only in territory of Turkish Republic and in case of arbitration courts of Samsun city Turkish Republic are authorized.
- 18)** Service and warranty terms are the responsibility of the importer company



"Time to heat up most efficiently"



PELLET SYSTEM

STYLISH DESING
MODERN HEATING
SOLUTIONS...



FOUR POWERFUL ADVANTAGES

CENTRAL HEATING
HOT WATER
STOVE&FIREPLACE